

Man & Machine advisory

Premium Waterproof Keyboard Recommended Cleaning Instructions

Really Cool, Really Cool+, Slim Cool, Slim Cool+, Slim Cool++



To clean a premium silicone Man & Machine keyboard while plugged into PC, press the left & right Control (“Ctrl”) keys together for 3 seconds to lock keys.

Clean the surface of the product by wiping, brushing, or spraying it using only clothes, sponges or soft bristle brushes.

DO NOT place the USB or PS/2 connector in fluid.

Either wipe with dry cloth or allow to air dry.

After cleaning, press both Control keys again for 3 seconds to unlock keys.

Recommended	Do Not Use
<p>Chlorine based (max 10% solution) - Chlorox, Novalsan, etc. Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc. Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc. Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc. Alcohol based - Cavicide, Isopropyl Alcohol, Medicide Dürr FD 322, FD 333 & 350, etc. Oxidizing - Hydrogen Peroxide 3% Solution, Lifeguard Series, etc. Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, Dürr FD 300 2%, Dürr FD 312 2%, etc. Soap & water</p>	<p>Petroleum based cleaning fluids, such as Gasoline, Turpentine & oil Acetone Greater than 10% bleach solutions Abrasive cleaners Temperature or pressure sterilization Buffing pads or scrubbing pads</p>

These instructions & recommendations have been prepared to advise the proper methods of cleaning your premium data entry product. Man & Machine, Inc. & your local distributor cannot assume responsibility for the application of cleaners. Any questions or concerns should be addressed prior to actual cleaning by contacting Man & Machine, Inc.



Proudly Made In the USA

www.man-machine.com • info@mmimd.com • Phone (301) 341-4900

The Designs That Inspired All Others
www.man-machine.com

Man & Machine advisory

Water Resistant Keyboards & All Mice Recommended Cleaning Instructions



U Cool, U Hot, Simply Cool, Mighty Mouse 5, Petite Mouse, Cool Mouse

To clean a water resistant keyboard Man & Machine keyboard (except for U Hot) while plugged into PC, press the left & right Control (“Ctrl”) keys together for 3 seconds to lock keys. For mice & U Hot disconnect from PC.

Clean the surface of the product by wiping, brushing or spraying it using only clothes, sponges or soft bristle brushes.

DO NOT place the USB or PS/2 connector in fluid.

Either wipe with dry cloth or allow to air dry.

After cleaning, press both Control keys again for 3 seconds to unlock keys.

Recommended	Do Not Use
<p>Chlorine based (max 10% solution) - Chlorox, Novalsan, etc. Formaldehyde based - Formaldehyde Solution 37%, Vinco Formaldegen, etc. Glutaraldehyde based - Aldacide 200, Lysofume, Wavicide, etc. Phenol based - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc. Alcohol based - Cavicide, Isopropyl Alcohol, Medicide Dürr FD 322, FD 333 & 350, etc. Oxidizing - Hydrogen Peroxide 3% Solution, Lifeguard Series, etc. Quaternary Ammonium - Roccal-D, Bacto-Sep, Parvosol, Dürr FD 300 2%, Dürr FD 312 2%, etc. Soap & water</p>	<p>Petroleum based cleaning fluids, such as Gasoline, Turpentine & oil Acetone Greater than 10% bleach solutions Abrasive cleaners Temperature or pressure sterilization Buffing pads or scrubbing pads</p>



These instructions & recommendations have been prepared to advise the proper methods of cleaning your premium data entry product. Man & Machine, Inc. & your local distributor cannot assume responsibility for the application of cleaners. Any questions or concerns should be addressed prior to actual cleaning by contacting Man & Machine, Inc.

Man & Machine advisory

Drape Recommended Cleaning Instructions

Cool Drape, Fitted Drape



Recommended

May be autoclaved for sterilization

- Chlorine based (max 10% solution)** - Chlorox, Novalsan, etc.
- Formaldehyde based** - Formaldehyde Solution 37%, Vinco Formaldegen, etc.
- Glutaraldehyde based** - Aldacide 200, Lysofume, Wavicide, etc.
- Phenol based** - Lysol I.C., Beaucoup, Magna Clean, Tek-Trol, etc.
- Alcohol based** - Cavicide, Isopropyl Alcohol, Medicide Dürr FD 322, FD 333 & 350, etc.
- Oxidizing** - Hydrogen Peroxide 3% Solution, Lifegard Series, etc.
- Quaternary Ammonium** - Roccal-D, Bacto-Sep, Parvosol, Dürr FD 300 2%, Dürr FD 312 2%, etc.
- Soap & water**

Do Not Use

- Petroleum based cleaning fluids, such as Gasoline, Turpentine & oil Acetone
- Greater than 10% bleach solutions
- Abrasive cleaners
- Temperature or pressure sterilization
- Buffing pads or scrubbing pads

Portable Keyboard Recommended Cleaning Instructions

CoolMIR, HotTooth



Recommended

Wipe clean with damp cloth

Do Not Use

Water or other fluids. Be sure not to get the white plastic casing wet

These instructions & recommendations have been prepared to advise the proper methods of cleaning your premium data entry product. Man & Machine, Inc. & your local distributor cannot assume responsibility for the application of cleaners. Any questions or concerns should be addressed prior to actual cleaning by contacting Man & Machine, Inc.

MAN & MACHINE

