

Special Keyboard Options

Make the best waterproof keyboard even better

Upgrade your keyboard with our optional features for added comfort and usability. Add backlight for low light environments. Choose MagFix or SCOP for hassle-free mounting on carts and trays. For additional protection add a fitted drape to your keyboard for single wipe flat surface disinfecting. Or let our engineers develop unique solutions for your applications.



BACKLIGHT Make it visible in the dark

Three levels of brightness for low-light environments. Each key is individually illuminated for superior visibility.

Attributes

- Available on Slim Cool, Really Cool and Slim Cool+ keyboards
- Power Consumption 60 to 135 mA depending on brightness setting. Expected maximum 200 mA
- Includes Switch off mode

MAGFIX Make it stick

Hidden magnets hold the keyboard in place on angled surfaces. No more dirt and microbes trapped in Velcro, tape or adhesives. Ideal for carts and keyboard trays.

Attributes

- Available on Slim Cool, Slim Cool+, Really Cool, Really Cool+, Mighty Mouse5 and Petite Mouse
- Maximum Field Density Magnets: 0.21 Tesla
- Ferrous surface required. Will not stick to Aluminum or Stainless Steel



SCOP Make it detachable

Variable lengths for easy cable management. Easily detach keyboard for remote cleaning.

Attributes

- Available on Slim Cool, Slim Cool+, Really Cool, Really Cool+, Mighty Mouse5 and Petite Mouse
- Cable Length options 57 cm and 27 cm for keyboard, 50 cm for mouse

FITTED DRAPE Make it one-wipe cleanable

Covers your Man & Machine keyboard with a form-fitting 100% silicone drape. The world's only one-wipe sterilizable cleaning solution.

Attributes

- Available for Really Cool and UCool keyboard
- Can be autoclaved. Upto 200° C
- Creates transparent flat surface

